

The screenshot shows the software interface for a ground fault tester. It features several input fields for 'Strom' (11.3 A), 'Widerstand' (213 mOhm), 'Spannung' (3.4 V), and 'Grenzwert' (397 mOhm). A 'Hauptfeld' contains a 'Timer' set to 16 seconds and 'Start', 'Reset', and 'Ende' buttons. A 'Gerät' dropdown is set to 7. On the right, a list of test results for six devices is displayed, including dates, times, and status (e.g., 'Status = Fehler', 'Status = Gut').

Labels on the left side of the screenshot:

- Schnittstellenauswahl
- Wahl der Archivierungsdatei
- Stromanzeige
- Widerstandsanzeige
- Spannungsanzeige
- Grenzwertanzeige
- Statusanzeigen
- Funktionstasten

Labels on the right side of the screenshot:

- Digitalwerte
- Prüfungsergebnisse
- Zähler (überschreibbar)
- Typenbezeichnung (überschreibbar)
- Zeitanzeige

Hinweis:

Die Einstellungen Prüfstrom und Grenzwert können nur am Prüfgerät vorgenommen werden.
 Alle anderen Funktionen sind sowohl per PC und per Gerät möglich, dabei hat die kleinere Zeiteinstellung Vorrang.